



OMNI® Low VOC Reducer Selection Guide



The below recommendations are only a general reference and should be used solely as a starting point for choosing the appropriate reducer. Your particular spray environment and job size may require slight adjustments.

Temperature

60°F (15°C)	65°F (18°C)	70°F (21°C)	75°F (24°C)	80°F (26°C)	85°F (29°C)	90°F (32°C)	95°F (35°C)
	MR294 <i>Primer / Sealer / Basecoat</i>						
		MR295 <i>Primer / Sealer / Basecoat</i>					
			MR296 <i>Primer / Sealer / Basecoat</i>				
	MR294 <i>Clearcoat / Single Stage</i>						MR297* <i>Basecoat</i>
		MR295 <i>Clearcoat / Single Stage</i>					<small>*must be mixed with MR296 reducer</small>
			MR296 <i>Clearcoat / Single Stage</i>				
						MR297* <i>Clearcoat/Single Stage</i>	
						<small>*must be mixed with MR296 reducer</small>	

Tips:

- A higher temp reducer in a clearcoat will allow the surface to stay open longer and provide additional leveling.
- Consider the job size when selecting the appropriate reducer. Larger jobs may require a higher temp reducer in order to maintain a “wet” edge.
- Where there is excessive air flow in the spray area, a higher temp reducer should be considered to minimize the potential for solvent entrapment.