

# **ALK-110**Fast-Dry Alkyd Enamel

### Reduction

If temperature is greater than 70°F / 21°C, reduce with Q160.

If temperature is less than 70°F or 21°C, reduce with Q50.

For electrostatic application, reduce with Q70.

Non-exempt solvents - Q50, Q160, Q70, etc. will raise VOC. To maintain VOC, use Q30.

Use of Fine Finish tip in airless / air-assisted airless can provide superior atomization and better finish.

## Conventional - Reduce 20-30%

Equipment	Spray Viscosity	Fluid Pressure (PSI)	Atomization Pressure (PSI)	Fluid Nozzle
Cup Gun	25 – 40" #2 EZ Zahn	N/A	40-50	1.4mm-1.8mm
Pressure Pot	30 – 45" #2 EZ Zahn	20 – 25	40-50	1.4mm-1.8mm

#### HVLP - Reduce 20-30%

Equipment	Spray Viscosity	Fluid Pressure (PSI)	Atomization Pressure (PSI)	Fluid Nozzle
Cup Gun	20- 40" #2 EZ Zahn	N/A	40-50**	1.4mm-1.8mm

<sup>\*\*</sup>atomization pressure should read <10 psi at the cap

#### Air-Assisted Airless - Reduce 15-20%

Equipment	Spray Viscosity	Fluid Pressure (PSI)	Atomization Pressure (PSI)	Tip
AA	40-60" #2 EZ Zahn	900 – 1300	20 – 40	0.011-0.014

## Airless - Reduce 5-15%

Equipment	Spray Viscosity	Fluid Pressure (PSI)	Tip
Airless	45-80" #2 EZ Zahn	1500-2200	0.011-0.014

