

# Release Note

---

Release Date : March 2020

Product Ver. : Civil 2020 (v2.1)



DESIGN OF CIVIL STRUCTURES

Integrated Solution System for Bridge and Civil Engineering

# Enhancements

1. Multiple stage post-tensioning in tendon
2. Auto division of the fiber section (Core and cover)
3. New option for Moving load optimization
4. Application rule change of Military Load Class
5. Improvement in calculation of torsional constant for closed composite section
6. Improvement of the element temperature calculation method for the composite section for C.S.
7. Improvement of the analysis speed for the inelastic time-history analysis
8. Improvement in GSD - Civil pushover hinge export
9. Bridge Assessment to the UK standard: CS 454/19
10. RC Design to IS 456:2000 & Crack calculations by IS 3370(Part 2):2009




### 1. Multiple stage post-tensioning in tendon




- Re-tensioning of tendon is now supported. Immediate losses and time-dependent losses which occurred before re-tensioning are removed and recalculated based on the summation of multiple stage stressing applied to the tendon starting from the time of re-tensioning.
- Re-tensioning of coupled tendon is not supported

▪ *Load > Temp./Prestress > Tendon Prestress*

Tensioning at stage 1



Re-tensioning at stage 2




Civil 2020v2.1


### 2. Auto division of the fiber section (core and cover)

- In earlier versions, the fiber section was to be manually divided into the core & cover regions and this was to be done for all such sections.
- Now, just the fiber hinge needs to be defined and the fiber division of the section can be done automatically, including differentiation for confined and un-confined concrete. Also, the fiber division can be equal size or auto size.


▪ **Properties > Inelastic Material > Fiber Division of Section**





Inelastic Properties Control Data




Fiber definition



Drag & Drop



Auto Size option



Equal Size option

### 3. New option for moving load optimization


- In earlier versions of midas, there was auto calculation to control the critical position of the analysis lanes in moving load optimization. Lane offset had to be provided manually.
- In this version, the limitation is removed as the number of analysis lanes can be specified by the user and this ensures that vehicle is placed at the extreme ends of the optimization lane.

- **Load > Moving Load > Traffic Line Lanes > Moving Load Optimization**
- **Load > Moving Load > Traffic Surface Lanes > Moving Load Optimization**

**Moving Load Optimization**

Lane Name : optimization lane

Traffic Lane Optimization Properties



**a : Eccentricity**

Optimization Lane 9 m

Lane Width 3 m

**Anal. Lane Offset 1.5 m**

Wheel Spacing 2 m

Margin 0 m

Eccentricity 0 m

Straddling Lane Type

Vehicular Load Distribution

Lane Element  Cross Beam


Cross Beam Group

Skew

Start 0 End 0 [deg]

Moving Direction


Forward  Backward  Both



**Define Moving Load Optimization**

Lane Name : optimization lane

Traffic Lane Optimization Properties



**a : Eccentricity**

Optimization Lane 9 m

Lane Width 3 m

Generate Analysis Lanes

Number of Lanes(2^N+1) N: 2

Offset from Centerline 1 m

Wheel Spacing 2 m

Margin 0 m

Eccentricity -5.1 m

Straddling Lane Type

Vehicular Load Distribution

Lane Element  Cross Beam

Cross Beam Group

Skew

Start 0 End 0 [deg]

Moving Direction

Forward  Backward  Both




Previous version

Civil 2020 v2.1

### 4. Application rule change of Military Load Class

- In earlier version, to obtain the most unfavorable condition for the structure, even the partial vehicle load was considered.
- Now, only complete vehicle would be considered to obtain the worst effect on the structure.


▪ *Load > Moving Load > Moving Load Code > POLAND > Vehicle Add Standard > Military Load Class*




## 5. Improvement in calculation of torsional constant for closed composite section

- The torsional constant calculation has been improved for composite section which has open cross-section before composite and closed cross-section after composite, e.g. Super T girder.
- Now, the torsional constant is calculated according to finite element based analysis thus calculating for both before composite and after composite separately.

### ▪ Properties > Section Properties > Composite



Part I



Part I + Part II

	Value(Before)	Value(After)	Unit
Area	5.361715e-001	1.230545e+000	m <sup>2</sup>
Asy	4.831434e-001	4.645265e-001	m <sup>2</sup>
Asz	6.130852e-001	5.972085e-001	m <sup>2</sup>
Ixx	7.834168e-003	1.506723e-002	m <sup>4</sup>
Iyy	1.011163e-001	2.928666e-001	m <sup>4</sup>
Izz	1.123795e-001	6.331598e-001	m <sup>4</sup>
Cyp	1.050000e+000	1.050000e+000	m
Cym	1.050000e+000	1.050000e+000	m
Czp	6.635581e-001	2.185895e-001	m
Czm	5.514419e-001	9.964105e-001	m
Qyb	0.000000e+000	0.000000e+000	m <sup>2</sup>
Qzb	0.000000e+000	0.000000e+000	m <sup>2</sup>
Peri:O	7.967478e+000	1.446748e+001	m
Peri:l	0.000000e+000	0.000000e+000	m
Center:y	1.050000e+000	1.500000e+000	m
Center:z	5.514419e-001	9.964105e-001	m
y1	-1.050000e+000	-1.050000e+000	m
z1	6.635581e-001	2.185895e-001	m
y2	1.050000e+000	1.050000e+000	m
z2	6.635581e-001	2.185895e-001	m
y3	4.070000e-001	4.070000e-001	m
z3	-5.514419e-001	-9.964105e-001	m
y4	-4.070000e-001	-4.070000e-001	m
z4	-5.514419e-001	-9.964105e-001	m

Close

Previous version




	Value(Before)	Value(After)	Unit
Area	5.361715e-001	1.230545e+000	m <sup>2</sup>
Asy	1.237778e-001	7.374340e-001	m <sup>2</sup>
Asz	2.125628e-001	2.803497e-001	m <sup>2</sup>
Ixx	6.700396e-003	1.916471e-001	m <sup>4</sup>
Iyy	1.011163e-001	2.928666e-001	m <sup>4</sup>
Izz	1.123795e-001	6.331598e-001	m <sup>4</sup>
Cyp	1.050000e+000	1.050000e+000	m
Cym	1.050000e+000	1.050000e+000	m
Czp	6.635581e-001	2.185895e-001	m
Czm	5.514419e-001	9.964105e-001	m
Qyb	0.000000e+000	0.000000e+000	m <sup>2</sup>
Qzb	0.000000e+000	0.000000e+000	m <sup>2</sup>
Peri:O	7.967478e+000	1.446748e+001	m
Peri:l	0.000000e+000	0.000000e+000	m
Center:y	1.050000e+000	1.500000e+000	m
Center:z	5.514419e-001	9.964105e-001	m
y1	-1.050000e+000	-1.050000e+000	m
z1	6.635581e-001	2.185895e-001	m
y2	1.050000e+000	1.050000e+000	m
z2	6.635581e-001	2.185895e-001	m
y3	4.070000e-001	4.070000e-001	m
z3	-5.514419e-001	-9.964105e-001	m
y4	-4.070000e-001	-4.070000e-001	m
z4	-5.514419e-001	-9.964105e-001	m

Close


Civil 2020v2.1

### 6. Improvement of the element temperature calculation method for the composite section for C.S.

- In earlier version, uniform temperature loads like system temperature, nodal temperature and element temperature were applied to transformed properties of composite beam elements.
- In new version, these loads are applied individually to each part based on temperature coefficient to predict more realistic behavior of structure, when composite section for construction stage are defined.



Previous version – Axial deformation & no bending




Civil 2020 v2.1 – Axial deformation & bending


### 7. Improvement in analysis speed for inelastic time history analysis

- The output for non-linear elastic time history analysis with fiber modelling could now be restricted to required elements or links. This drastically reduces the overall analysis time of the model.



- Properties > Inelastic Properties Control Data > Select Inelastic Hinge Result Output (Element)
- Properties > Inelastic Properties Control Data > Select Inelastic Hinge Result Output (General Link)



Hinge Result Output (General Link)



Hinge Result Output (Element)



- Duration : 30 Second (3000Step)
- Model scale : 86 Beam elements
- Fibercell : 28,248Pieces

```

< TIME HISTORY LOADCASE NO. 2 / 2 >
* ANALYSIS TYPE : NONLINEAR
* ANALYSIS METHOD : DIRECT INTEGRATION
* TIME HISTORY TYPE : TRANSIENT
* MASS TYPE : LUMPED MASS
* DAMPING METHOD : MASS & STIFFNESS PROPORTIONAL (RAYLEIGH DAMPING)
* INCORE MULTI-FRONTAL SOLVER
-----TIME STEPS-----SUBSTEPS-- --ITERATIONS-- --ELAPSED / TOTAL TIME----
3000 / 3000 3000 6031 845.480 / 845.480 [sec]
* SAVE INELAS
* ELEMENT OUT
DISPLACEMENT
PREPARING F
ELEM. :
INELASTIC H
FIBER BEAM
  
```

**v1.2** Analysis Time Result Output Time Other Times 1654.19 sec

**v2.1** 64.8sec

```

-----SOLUTION TERMINATED-----
YOUR MIDAS JOB IS SUCCESSFULLY COMPLETED.
TOTAL SOLUTION TIME...: 1654.19 [SEC]
-----SOLUTION TERMINATED-----
YOUR MIDAS JOB IS SUCCESSFULLY COMPLETED.
TOTAL SOLUTION TIME...: 64.80 [SEC]
  
```

2020 v1.2

2020 v2.1

### 8. Improvement in GSD Pushover Hinge Export

- In earlier version, the yield moment was taken from the PMM interaction curve generated for the design instead of idealized curve in the Moment-Curvature curve.
- In this version, the yield moments depending on axial forces are taken from the idealized curve in the moment-curvature curve when exporting hinge data for pushover analysis.

- **Pushover > Hinge Properties > Define Pushover Hinge Type/Properties**

Section View: Cvl\_Column | Interaction Curve | Moment-Curvature Curve | Stress Contour

Mode:  Angle: 0 Deg.  P-My  P-Mz  Load Combination: LC

Code: Eurocode2:04

Checking Ratio:  Keep M/P constant  Keep M constant  Keep P constant

Hoop Type:  Tie

	P (kN)
1	24908.970
2	18768.158
3	17334.453
4	16838.642
5	15794.918
6	14720.885
7	13621.335
8	12492.856
9	11357.819
10	10227.107
11	9117.409
12	8081.230
13	7329.061
14	6593.286
15	5639.075
16	4577.785
17	3493.591
18	2354.494
19	1170.870
20	7.722
21	-1225.595
22	-2540.706
23	-3900.148
24	-5438.150
25	-6146.546

Moment Curvature Curve  
Axial load = 9117.41  
Neutral Axis Angle = 0

Cracked Moment of Inertia (I<sub>crack</sub>) = 0.0373679 m<sup>4</sup>

State	Curvature *10 <sup>-3</sup> (1/m)	Moment (kN×m)
a.Crack	1.046420	2540.213
b.Yield(Init.)	4.991872	5108.490
c.Yield	7.474051	5658.068
d.Ultimate(conc)	43.595	4855.292
e.Ultimate(rebar)	-	-
f.Yield(ideal)	5.485665	5613.820

Strain Diagram  
C: 0  
R: 0

Point Number : 0  
Concrete Strain : 0  
Rebar Strain : 0  
Neutral Axis Depth : 0 m

Export Report Close


Previous version

Civil 2020 v2.1

### 9. Bridge Assessment to the UK standard: CS 454/19

- Level 1 assessment can be performed now for **PSC Box & PSC Composite sections** in midas Civil. All model 2 vehicle is also introduced in accordance to CS 454 Assessment code.
- Assessment load combinations can be defined to obtain output for strength & service limit states.

- **Load > Moving Load > Moving Load Code> BS> Vehicle > CS 454 Assessment**
- **Rating> PSC Bridge > CS 454/19**



**Define Standard Vehicular Load**

Standard Name: CS 454 Assessment

Vehicular Load Properties

Vehicular Load Name: ALL MODEL 2(UDL+KEL)

Vehicular Load Type: ALL MODEL 2(UDL+KEL)

UDL

KEL

Lane Factor

CS 454  User-defined

Loaded length, L(m)	UDL (kN/m)	KEL (kN)
$L \leq 20m$	$\frac{230}{L^{0.67}}$	82
$20m < L < 40m$	$\frac{336}{L^{0.67}} \cdot \frac{1}{1.92 - 0.023 L}$	$\frac{120}{1.92 - 0.023 L}$
$40m \leq L \leq 50m$	$\frac{336}{L^{0.67}}$	120
$L > 50m$	$\frac{36}{L^{0.1}}$	120

Category for K-Factor

Traffic/Surface Category: Hp

Load Level: 40t

OK Cancel Apply

**Assessment Parameter**

Condition Factor(Fc): 1

Value of Gamma\_m(Ultimate limit States)

Characteristic Strength  Worst Credible Strength

User Input

Modify Design Parameters

Strength Limit State

Flexure  Shear  Torsion

Serviceability Limit State

Stress/Crack

Detail Report

Ultimate Limit State  Serviceability Limit State

OK Cancel

**Define Assessment Case**

Name	Limit State	Comb. Type	Gamma_f3
SLS-1	SLS	Comb1	1
SLS-2	SLS	Comb2	1
SLS-3	SLS	Comb3	1
SLS-4	SLS	Comb4	1
ULS-1	ULS	Comb1	1.1
ULS-2	ULS	Comb2	1.1
ULS-3	ULS	Comb3	1.1
ULS-4	ULS	Comb4	1.1
*			

Static Load Cases and Factors(Gamma_f1)	
Static Load Cases	Factor
D(ST)	1.0000
SDL(ST)	1.2000
L(ST)	1.0000
*	

Moving Load Cases and Factors(Gamma\_fi)

Standard Vehicle HA(MV) 1.2

Special Vehicle 0

Copy Assessment Load Combination

Copy into General Load Combination

Close

All Model 2 vehicle


Assessment Parameters

Load combination for assessment

### 9. Bridge Assessment to the UK standard: CS 454/19

- Assessment results could be viewed in tabular format in midas Civil itself and these can be exported to excel file as well.
- Summary as well as detailed report is provided for Flexural, Shear, Torsion & Service limit state for Class 1 and 2 category.

Rating > PSC Bridge > CS 454/19



Assessment Result Tables

Element	Part	Rating Case	v	vt	vtu	y1	vtu(y1/550)	A	Check
10	I[11]	ULS-1_Fxx(Max)	-825.1060	0.000	6000.0	3.0	32727.2727	7.2718	OK
10	I[11]	ULS-1_Fxx(Min)	-1473.094	0.000	6000.0	3.0	32727.2727	4.0731	OK
10	I[11]	ULS-1_Fyy(Max)	-825.1060	0.000	6000.0	3.0	32727.2727	7.2718	OK
10	I[11]	ULS-1_Fyy(Min)	-1473.094	0.000	6000.0	3.0	32727.2727	4.0731	OK
10	I[11]	ULS-1_Fzz(Max)	-825.1060	0.000	6000.0	3.0	32727.2727	7.2718	OK
10	I[11]	ULS-1_Fzz(Min)	-1473.094	0.000	6000.0	3.0	32727.2727	4.0731	OK
10	I[11]	ULS-1_Mxx(Max)	-825.1060	0.000	6000.0	3.0	32727.2727	7.2718	OK
10	I[11]	ULS-1_Mxx(Min)	-1473.094	0.000	6000.0	3.0	32727.2727	4.0731	OK
10	I[11]	ULS-1_Myy(Max)	-825.1060	0.000	6000.0	3.0	32727.2727	7.2718	OK
10	I[11]	ULS-1_Myy(Min)	-1473.094	0.000	6000.0	3.0	32727.2727	4.0731	OK

Tabular output in midas Civil

**1. Design Condition**

Design code	Element	Part(Node)
CS454/19	10	I(11)

**2. Assessment factors**

The following factors, as in BD 86/11, have been used to compare results of different configurations and combinations.

- Adequacy factor:
 
$$A = \frac{R_a^*}{S_a^*}$$
- Special Vehicle reserve factor with standard vehicle:
 
$$\psi = \frac{R_a^* - (S_D^* + S_{ST}^*)}{S^*}$$
- Special Vehicle reserve factor without standard vehicle:
 
$$\psi^* = \frac{R_a^* - S_D^*}{S^*}$$

Where:

- R<sub>a</sub><sup>\*</sup> : the assessment resistance
- S<sub>D</sub><sup>\*</sup> : the assessment load effect due to combined dead and superimposed dead loads
- S<sub>ST</sub><sup>\*</sup> : the assessment load effect due to standard vehicle
- S<sup>\*</sup> : the assessment load effect due to standard vehicle
- S<sub>a</sub><sup>\*</sup> : the assessment load effect due to standard vehicle

**3. Flexural Reserve Factors**

Assessment Case	Load Effect	R <sub>a</sub> <sup>*</sup> (kN.m)	S <sup>*</sup> (kN.m)	S <sub>D</sub> <sup>*</sup> (kN.m)	S <sub>ST</sub> <sup>*</sup> (kN.m)	S <sub>a</sub> <sup>*</sup> (kN.m)	A	ψ	ψ*	Check
ULS-1_Fxx(Max)	Positive	3208.885	-	6717.530	1186.514	7904.044	0.406	-	-	NG
ULS-1_Fxx(Min)	Positive	3208.885	-	6717.530	0.000	6717.530	0.478	-	-	NG
ULS-1_Fyy(Max)										
ULS-1_Fyy(Min)										

**4. Shear Reserve Factors**

Assessment Case	R <sub>s</sub> <sup>*</sup> (kN)	S <sup>*</sup> (kN)	S <sub>D</sub> <sup>*</sup> (kN)	S <sub>ST</sub> <sup>*</sup> (kN)	S <sub>a</sub> <sup>*</sup> (kN)	A	ψ	ψ*	Check
ULS-2_Fxx(Max)	429.055	-	-1245.888	99.981	-158.499	2.707	-	-	OK
ULS-2_Fxx(Min)	605.191	-	-1245.888	-390.229	-158.499	3.818	-	-	OK
ULS-2_Fyy(Max)	429.055	-	-1245.888	99.981	-158.499	2.707	-	-	OK
ULS-2_Fyy(Min)	605.191	-	-1245.888	-390.229	-158.499	3.818	-	-	OK
ULS-2_Fzz(Max)	429.055	-	-1245.888	99.981	-158.499	2.707	-	-	OK
ULS-2_Fzz(Min)	605.191	-	-1245.888	-390.229	-158.499	3.818	-	-	OK
ULS-2_Mxx(Max)	429.055	-	-1245.888	99.981	-158.499	2.707	-	-	OK

Excel report output

## 10. RC Design to IS 456:2000 & Crack calculations by IS 3370(Part 2):2009

- Reinforced Concrete Design as per IS 456: 2000 is now available in midas civil, where we can perform Beam Design, Beam Checking, Column Design, Column Checking
- We can generate Graphic/Detailed reports which include both Ultimate Limit State and Serviceability Limit State checks as per IS 456:2000. Also, Crack Width Checks as per IS 3370 (Part-2):2009 can be obtained for Beams.

Design > RC Design > IS456:2000

**Concrete Design Code**

Design Code : IS456:2000

Apply Special Provisions for Seismic Design

Moment Redistribution Factor for Beam : 1

Torsion Design

IS 3370(Part 2):2009 Crack Width Check

Crack Width due to Temperature & Moisture - Annex A


- Estimated Shrinkage Strain: 0.0025
- Estimated Total Thermal Contraction after Peak Temperature due to Heat of Hydration: 0.0025
- T1 (C) Fall in Temperature between the hydration peak and ambient: 30

Crack Width in Mature Concrete - Annex B

- Limiting Design Surface Crack Width(mm): 0.2

OK Close

Code options for IS 456:2000 & IS 3370(Part 2):2009



**Preview Window**  
No: 4

3. Bending Moment

1. Design Condition

Design Code IS456:2000  
Unit System kN, m  
Member Number 4  
Material Data fck = 40000, fy = 415000, fyw = 415000 KPa  
Column Height 4 m  
Section Property Column (No: 2)

Rebar Pattern	Pos 1	Pos 2	Pos 3
Layer 1	6-P32	10-P32	--
Layer 2	6-P32	10-P32	--

Total Rebar Area Ast = 0.0514688 m<sup>2</sup> (RhoSt = 0.2145)

2. Applied Loads

Load Combination 3 AT (I) Point  
N<sub>Ed</sub> = 341.642 kN, M<sub>Edy</sub> = 126.847, M<sub>Edz</sub> = 9.56598, M<sub>Ed</sub> = 127.207 kN-m

3. Axial Forces and Moments Capacity Check

Concentric Max. Axial Load N<sub>Rdmax</sub> = 17327.4 kN

Axial Load Ratio N<sub>Ed</sub>/N<sub>Rd</sub> = 341.642 / 1074.14 = 0.318 < 1.000 ..... O.K

Moment Ratio M<sub>Edy</sub>/M<sub>Rdy</sub> = 126.847 / 398.879 = 0.318 < 1.000 ..... O.K

M<sub>Edz</sub>/M<sub>Rdz</sub> = 9.56598 / 29.1810 = 0.328 < 1.000 ..... O.K

M<sub>Ed</sub>/M<sub>Rd</sub> = 127.207 / 399.945 = 0.318 < 1.000 ..... O.K

Graphic report for beam & column design & checking

MIDAS/Text Editor - [1\_Model\_IS456\_RCDesign.ruc]

```

00111
00112
00113
00114
00115
00116
00117
00118
00119
00120
00121
00122
00123
00124
00125
00126
00127
00128
00129
00130
00131
00132
00133
00134
00135
00136
00137
00138
00139
00140
00141
00142
00143
00144
00145
00146
00147
00148
00149
00150
00151
00152
00153
00154
00155
00156
00157
00158
00159
00160
00161
00162
00163
00164
00165
00166
00167
00168
00169
00170
00171
00172
00173
00174
00175
00176
00177
00178
00179
00180
00181
00182
00183
00184
00185
00186
00187
00188
00189
00190
00191
00192
00193
00194
00195
00196
00197
00198
00199
00200
00201
00202
00203
00204
00205
00206
00207
00208
00209
00210
00211
00212
00213
00214
00215
00216
00217
00218
00219
00220
00221
00222
00223
00224
00225
00226
00227
00228
00229
00230
00231
00232
00233
00234
00235
00236
00237
00238
00239
00240
00241
00242
00243
00244
00245
00246
00247
00248
00249
00250
00251
00252
00253
00254
00255
00256
00257
00258
00259
00260
00261
00262
00263
00264
00265
00266
00267
00268
00269
00270
00271
00272
00273
00274
00275
00276
00277
00278
00279
00280
00281
00282
00283
00284
00285
00286
00287
00288
00289
00290
00291
00292
00293
00294
00295
00296
00297
00298
00299
00300
00301
00302
00303
00304
00305
00306
00307
00308
00309
00310
00311
00312
00313
00314
00315
00316
00317
00318
00319
00320
00321
00322
00323
00324
00325
00326
00327
00328
00329
00330
00331
00332
00333
00334
00335
00336
00337
00338
00339
00340
00341
00342
00343
00344
00345
00346
00347
00348
00349
00350
00351
00352
00353
00354
00355
00356
00357
00358
00359
00360
00361
00362
00363
00364
00365
00366
00367
00368
00369
00370
00371
00372
00373
00374
00375
00376
00377
00378
00379
00380
00381
00382
00383
00384
00385
00386
00387
00388
00389
00390
00391
00392
00393
00394
00395
00396
00397
00398
00399
00400
00401
00402
00403
00404
00405
00406
00407
00408
00409
00410
00411
00412
00413
00414
00415
00416
00417
00418
00419
00420
00421
00422
00423
00424
00425
00426
00427
00428
00429
00430
00431
00432
00433
00434
00435
00436
00437
00438
00439
00440
00441
00442
00443
00444
00445
00446
00447
00448
00449
00450
00451
00452
00453
00454
00455
00456
00457
00458
00459
00460
00461
00462
00463
00464
00465
00466
00467
00468
00469
00470
00471
00472
00473
00474
00475
00476
00477
00478
00479
00480
00481
00482
00483
00484
00485
00486
00487
00488
00489
00490
00491
00492
00493
00494
00495
00496
00497
00498
00499
00500
    
```

( ) Compute moment magnification factors for major axis(DBy,DSy).  
 -. Cmy = 0.85 (Default or User defined value)  
 -. DBy < 1.0 --> DBy = 1.00  
 -. DSy = 1.00 (Default value)

( ) Compute minimum eccentric moments(Mmin)  
 -. Emin = MAX[ MAX[LyLz]/500 \* Dmax/30, 20] = 0.028 m.  
 -. Mmin\_y = Pu \* Emin = 9.57 kN-m.

( ) Compute magnified moments.

\*. DESIGN CODE : IS456:2000, \*.UNIT SYSTEM : kN, m  
 \*.MEMBER : Member Type = BEAM, HEMB = 10

\*.DESCRIPTION OF BEAM DATA (ISEC = 1) : Beam  
 Section Type : Rectangle (RECT)  
 Beam Length (Span) = 6.000 m.  
 Section Depth (Hc) = 0.600 m.  
 Section Width (Bc) = 0.300 m.  
 Concrete Strength (fck) = 30000.000 KPa.  
 Main Rebar Strength (fy) = 415000.000 KPa.  
 Stirrups Strength (fyw) = 415000.000 KPa.  
 Modulus of Elasticity (Es) = 200000000.000 KPa.

\*. FORCES AND MOMENTS AT CHECK POINT <I> :  
 Positive Bending Moment P-M\_Ed = 30.82 kN-m., LCB = 1  
 Negative Bending Moment N-M\_Ed = 164.95 kN-m., LCB = 2  
 Shear Force V\_Ed = 85.03 kN., LCB = 1  
 Torsion T = 2.84 kN-m., LCB = 11

\*. REINFORCEMENT PATTERN :  
 Location i di (m.) Rebar Asi (m<sup>2</sup>.)  
 Top 1 0.040 2-P20 0.00063  
 Bottom 1 0.040 2-P20 0.00063  
 Stirrups : 2.0-P12 @300

[[[\*]]] ANALYZE SHEAR AND TORSION CAPACITY.

( ) Compute design parameters.  
 -. alpha = 0.642857  
 -. beta1 = 0.8400  
 -. Gamma\_m = 1.50 (for concrete).  
 -. fcd = fck / Gamma\_m = 20000.000 KPa.  
 -. Gamma\_s = 1.15 (for Fundamental).  
 -. fyd = fyk / Gamma\_s = 36089.565 KPa.

( ) Check area of tensile reinforcement (Rectangular-beam).  
 -. fyk = 415000.0000 KPa.  
 -. ecu = 0.0035  
 -. est = fy/1.15Es + 0.002 = 0.0038  
 -. As\_max1 = (fcd\*Bc/fy)\*(beta1\*ecu\*d/(est+ecu)) = 0.0040 m<sup>2</sup>.  
 -. As\_max2 = 0.04 \* (Bc\*Hc) = 0.0060 m<sup>2</sup>.  
 -. As\_max = min[ As\_max1, As\_max2 ] = 0.0040 m<sup>2</sup>.  
 -. As\_min = 0.85\*bt\*d/fy = 0.0003 m<sup>2</sup>.  
 -. As\_prov = 0.0006 m<sup>2</sup>.  
 -. As\_min < As\_prov < As\_max ----> O.K !

Ready Ln 208 / 392, Col 57

Detailed text output with crack calculations