

The below recommendations are only a general reference and should be used solely as a starting point for choosing the appropriate reducer. Your particular spray environment and job size may require slight adjustments.

Temperature

60°F (15°C)	65°F (18°C)	70°F (21°C)	75°F (24°C)	80°F (26°C)	85°F (29°C)	90°F (32°C)	95°F (35°C)
	P850-1692 <i>Primer / Sealer / Basecoat</i>						
			P850-1693 <i>Primer / Sealer / Basecoat</i>				
	P850-1692 <i>Clearcoat / Single Stage</i>				P850-1694 <i>Primer / Sealer / Basecoat</i>		
			P850-1693 <i>Clearcoat / Single Stage</i>				P850-1695 <i>Primer / Sealer / Basecoat</i>
				P850-1694 <i>Clearcoat / Single Stage</i>			
					P850-1695 <i>Clearcoat / Single Stage</i>		
							P850-1696 <i>Clearcoat / Single Stage</i>

Tips:

- A higher temp reducer in a clearcoat will allow the surface to stay open longer and provide additional leveling.
- Consider the job size when selecting the appropriate reducer. Larger jobs may require a higher temp reducer in order to maintain a "wet" edge.
- Where there is excessive air flow in the spray area, a higher temp reducer should be considered to minimize the potential for solvent entrapment.